

How to Construct a Bait Station


Modified T-type

Materials


- Eight feet of 4-inch PVC/NDS drainage pipe
- One T-junction
- Two 4-inch to 3-inch reducers
- Two 45° connectors
- One end cap
- PVC tape, PVC cement, or silicon glue
- Label

Assembly

1. Cut the PVC pipe into one 2-foot section and four 1.5-foot sections.




2. Attach the T-junction to the 2-foot pipe.




3. Attach two 1.5-foot sections into opposite ends of the T-junction.

4. Place the 45° connectors on the ends of the bait station legs (1.5-foot sections).



5. Place the two remaining 1.5-foot sections on the ends of the 45° connectors.

6. Place the 4-inch to 3-inch reducers on the ends of the extensions and the end cap on top of the 2-foot section.



7. Attach a service container label near the top of the bait station.



Visit www.groundsquirrelbmp.com for more information about ground squirrel management.